

「銀河」運用記録 "GINGA" Daily Report

Ver 1.71

198 9 MONTH : 6 DAY : 13 Y+ 858Written by : I. HatakeyamaOPERATION: NGC104 RGP / NGC104M. Takizawa

	[PASS 1]	[PASS 2]	[PASS 3]	[PASS 4]	[PASS 5]
NO.	890612-1236	890612-1339	890612-1443	890612-1546	890613-0102
AOS	17:47:40	19:28:20	21:09:50	22:51:10	0:33:10
LOS	17:59:25	19:41:44	21:23:13	23:04:50	0:45:37
ELMX	13.83° 53:33	42.51° 34:48	84.20° 16:16	79.27° 57:53	33.53° 39:20
COMMANDS	SH REP BC ENA-1 05 00 00 00 00 00 MNV START BC ENA-1 05 00 00 7F 00 29 SLEW(-) BC ENA-1 05 00 00 00 00 00 MNV START BC ENA-1 05 00 00 05 13 7D PC CLR/WRT/CHK OG-1	BC ENA-1 05 00 00 00 00 00 MNV START BC ENA-1 05 45 8A 93 00 00 MNV START BC ENA-1 05 00 00 00 00 00 MNV START BC ENA-1 05 00 00 05 13 7D PC CLR/WRT/CHK OG-1	SH REP BC ENA-1 05 00 00 00 00 00 MNV START BC ENA-1 05 00 00 7F 00 71 SLEW(-) BC ENA-1 01 42 BC ENA-1 05 00 00 00 00 00 MNV START BC ENA-1 05 00 00 7F 00 B3 PC CLR/WRT/CHK OG-1	SH REP PC CLR/WRT/CHK OG-1	SH REP BC ENA-1 05 00 00 00 00 00 MNV START BC ENA-1 05 00 00 22 00 3A MNV START BC ENA-1 01 02 PC CLR/WRT/CHK OG-1 MNV STOP BC ENA-1 05 00 00 00 00 00 MNV START BC ENA-1 05 00 00 7F 00 B3
TLMS	Rep	レンジ=7"	Rep	Rep	Rep
ACS	N-E-N-SSE M-C-M-(M-E)	N-M-N-SSE M-V-M-(M-E)	N-E-N-SSE M-C-M-(M-E)	N-E-N-SSE M-C-M-(M-E)	N-E-N-SSE M-C-M-(M-E)
EVENT	6/2 17:30 (239.72) (100.71) (288.94)	6/2 18:00 (239.77) (100.76) (287.82)		6/2 22:12 (240.06) (101.25) (289.46)	
S	17:56:00	19:38:00	21:19:00	23:01:00	0:42:02
PC PLAN	001 OG-5 EXE 17:58 002 BIT MED 18:00 003 TMS ON 18:02 007 SLEW(-) 18:10 013 SLEW(+) 18:32 014 OG-7 EXE 18:36 029 OG-4 EXE 18:54 037 OG-5 EXE 19:10 038 SLEW(-) 19:12 044 OG-2 EXE 19:24 045 OG-3 EXE 19:26	001 OG-5 EXE 19:40 002 BIT MED 19:42 003 TMS ON 19:44 006 SLEW(-) 19:50 012 SLEW(+) 20:02 018 LHV RED 20:14 035 OG-5 EXE 20:48 038 SLEW(+) 20:54 044 OG-2 EXE 21:06 045 OG-3 EXE 21:08	001 OG-5 EXE 21:21 002 BIT MED 21:23 003 TMS ON 21:25 014 BIT Hi 21:47 018 OG-6 EXE 21:55 019 SLEW(+) 21:57 024 OG-4 EXE 22:07 031 SLEW(-) 22:21 032 BIT Hi 22:23 033 OG-5 EXE 22:25 045 OG-2 EXE 22:46 046 OG-3 EXE 22:51	001 OG-5 EXE 23:03 002 TMS ON 23:05 018 OG-6 EXE 23:37 032 OG-5 EXE 00:05 033 BIT MED 00:11 044 OG-2 EXE 00:29 045 OG-3 EXE 00:31	001 OG-5 EXE 00:44:00 002 BIT LOW 00:46:00 003 TMS ON 00:48:00 018 SLEW(+) 01:18:00 019 OG-4 EXE 01:20:00 028 SLEW(-) 01:38:00 029 BIT LOW 01:40:00 030 OG-5 EXE 01:42:00 070 LHV RED 03:02:00 071 ASM MODE 03:04:00 079 OG-5 EXE 03:20:00 345 LHV RED 12:12:00 346 ASM MODE 12:14:00 349 OG-5 EXE 12:20:00 389 LHV RED 13:40:00 390 ASM MODE 13:42:00 391 SLEW(+) 13:44:00 404 OG-4 EXE 14:10:00 411 BIT LOW 14:24:00 412 SLEW(-) 14:26:00 413 OG-5 EXE 14:28:00 436 LHV RED 15:14:00 437 ASM MODE 15:16:00 451 OG-7 EXE 15:44:00 452 SLEW 360 15:46:00 463 BIT LOW 16:08:00 464 OG-5 EXE 16:10:00 484 LHV RED 16:50:00 485 ASM MODE 16:52:00
COMMANDS	MAPのために5°回したことをうっかり忘れ、SUN ANGLEをそのまま使ってしまう、5パスのチョイよせパラメーターをまちがえてしまいましたか、途中で"MNVS STOP"したため結果はよせたことになりました。どうもすみません。(注) コメントいっぱいありました。				
SUN ANGLE	157.0 - 157.2	SUN ANGLE 157.6 °C	MIN. -BAT-V(EOD)	15.5 V (A 18.8 V)	15.5 V (A 18.8 V)